



Inline demineralisation cartridges

The demineralisation cartridge contains Mixed Bed resin type. Its main application is purification of pre-filtered water after an RO system. The cartridge allows final and complete demineralisation of water. Demineralised water is mainly used in aquaria, laboratories and dental treatment facilities.

Application

The filter can be easily mounted in most types of filtration systems. It reaches its maximum efficiency and lifespan while working with water already filtered by a reverse osmosis system.

Ion exchange resin

The Medion Mixed Bed resin is a high quality mixture of ion exchange media. The resin is composed of regenerated media - highly acidic cation resin and highly alkaline anion resin.

Technical data

Max flow	2,5 L . min.
Max pressure	3,5 bar
Work temperature	2-45 deg. C
Connection	2 x Stem 1/4"
Measurements	27 cm (L), Ø 2.5" (64 mm)
Resin capacity	0,5 L

Cartridge efficiency highly dependant on inlet water quality. Installation in reverse osmosis systems recommended.

DEMI 2,5" cartridges

www.greenfilter.com.pl